

TRIAC DRIVE ACCESSORIES



Pressure roller for TRIAC DRIVE

115.274: Pressure roller 12 mm

115.176: Pressure roller 30 mm

115.186: Pressure roller 38 mm



Guide handle for TRIAC DRIVE

115.284: Guide handle



Single supporting carrier for TRIAC DRIVE

115.276: Single supporting carrier



Double supporting carrier for TRIAC DRIVE

115.275: Double supporting carrier

Overlap welding nozzle with/without grip, inside push-fit on TRIAC DRIVE



115.701: Overlap welding nozzle 30 mm, without grip, inside, push-fit

115.279: Overlap welding nozzle 30 mm, with grip, inside, push-fit

115.703: Overlap welding nozzle 38 mm, without grip, inside, push-fit

115.281: Overlap welding nozzle 38 mm, with grip, inside, push-fit

115.699: Overlap welding nozzle 12 mm, without grip, inside, push-fit

115.283: Overlap welding nozzle 12 mm, with grip, inside, push-fit

Overlap welding nozzle with/without grip, outside push-fit on TRIAC DRIVE



115.702: Overlap welding nozzle 38 mm, without grip, outside, push-fit

115.280: Overlap welding nozzle 38 mm, with grip, outside, push-fit

115.700: Overlap welding nozzle 30 mm, without grip, outside, push-fit

115.278: Overlap welding nozzle 30 mm, with grip, outside, push-fit

115.698: Overlap welding nozzle 12 mm, without grip, outside, push-fit

115.282: Overlap welding nozzle 12 mm, with grip, outside, push-fit